

The formula we use is

$$\text{Unfolded Length} = \text{Flange Length 1} + \text{Flange Length 2} - \text{Deduction Value}$$

I've attached an image so that you can see how the lengths are measured in different angular cases.

Seth A. Hindman \ (Autodesk\

