

ug_setPartAttrValue

Synopsis

```
Defun: ug_setPartAttrValue(
    String, $title,
    String, $value )
@{...} Integer;
```

Description:

Creates a part attribute with a given title and value in the given file.
Use the name and the value of the attribute to set it.

For example, if the title is to be "my_attr" in the current part and its
value is to be Steel, use:

```
ug_setPartAttrValue ( "my_attr", "Steel");
```

Input Arguments:

title - Specify the title of the attribute

value - Specify the value of the attribute

Returns:

Integer- success[0] or failure[!= 0]

See Also: