


Thermisch-mech. Submodell in WB 12.1:

Eingabebefehl im Gesamtmodell:



Eingabebefehl im Submodell unter „Randbedingungen“:

```
/prep7
cmsel, s, area
nwrite, area, node
alls
nwrite, alles, node
save
fini
/clear
resume, ..../file, db

/post1
file, ..../file, rst
set, last
/nopr
cbdo, area, node, , cbdo, cbdo, , , , 0
/gopr
fini
/clear
```

```
/post1
file,..../file,rth
set,1,last
/nopr
bfint,alles,node,,bfin,bfin,,,,0
/gopr
```

```
fini
resu
/prep7
/nopr
/inp,cbdo,cbdo
/inp,cbdo,cbdo,, :cb1
/inp,bfin,bfin
/gopr
alls
/solu
```