

```

PRT:C:\Megatech\MegaCAD 2014 (32) 3D\prt\*.PRT
MAC:C:\Megatech\MegaCAD 2014 (32) 3D\mac\*.MAC
CDL:C:\Megatech\MegaCAD 2014 (32) 3D\cdl\*.CDL
FNT:C:\Megatech\MegaCAD 2014 (32) 3D\FONT\*.VFT
TMP:C:\Megatech\MegaCAD 2014 (32) 3D\TMP\*.TMP
KFN:
DIS:0
BAT:C:\Megatech\MegaCAD 2014 (32) 3D\*.MBT
PLP:C:\Megatech\MegaCAD 2014 (32) 3D\prt\*.PRT
PLS:C:\Megatech\MegaCAD 2014 (32) 3D\prt\*.SLD
PLH:C:\Megatech\MegaCAD 2014 (32) 3D\HPG\*.PLT
PLD:HPLJII300
PLC:1
PLQ:1
PLB:8
PLV:1
PLF:1
PLU:9600
9600 */
PLA:6
PLT:HP_GL
PL0:0,0,47560,33640,1189.0MM,841.0MM
PL1:0,0,33640,23760,841.0MM,594.0MM
PL2:0,0,23760,16800,594.0MM,420.0MM
PL3:0,0,16800,11880,420.0MM,297.0MM
PL4:0,0,11880,8400,297.0MM,210.0MM
DXI:1
DXO:1
PLW:3
PLX:0.300000
PLY:38
PLZ:C:\Megatech\MegaCAD 2014 (32) 3D\dxfl\*.DXF
INS:C:\Programme\Megatech\MegaCAD 2014 (32) 3D\*
NUP:1
NUD:7
LPT:LPT1
PAF:0.025000
PLL:6
XONN/XOFF */
PKO:150.0,150.0
PSB:1
TXT:C:\Megatech\MegaCAD 2014 (32) 3D\*.TXT
DIG:0,1,SUMMA
INF:C:\Megatech\MegaCAD 2014 (32) 3D\*.INF
DBF:C:\Megatech\MegaCAD 2014 (32) 3D\*.DBF
FMT:C:\Megatech\MegaCAD 2014 (32) 3D\*.FMT
DIN:0

```

# megacad.ini

```

/* Drawing file path */
/* Macro file path */
/* Co-ordinate data file path */
/* Text font file path */
/* Drive for temporary files */
/* Vektorfonts china */
/* Button 1=off 0=on */
/* Path for Megacad Batch files*/
/* Path for .PRT Inputfiles */
/* Path for .SLD Inputfiles */
/* Path for .HPG Outputfiles */
/* Printername (from print.doc)*/
/* Plotter datum point centre=1 bottom left = 0 */
/* Seriell Interface 1/2/3 or 4*/
/* Databits 8 or 7 */
/* Stopbits 1 or 2 */
/* Parity 1 = none 2 = odd 3 = even */
/* Baudrate 75 110 150 200 300 600 1200 2400 4800

/* How many plotter pens */
/* Plotter language (plotter.doc) */
/* DIN A0 xmin ymin xmax ymax x */
/* DIN A1 Plotter Resolution and paper size in mm*/
/* DIN A2 Plotter Resolution and paper size in mm*/
/* DIN A3 Plotter Resolution and paper size in mm*/
/* DIN A4 Plotter Resolution and paper size in mm*/
/* 1=mm 2=inch 3=cm 4=m */
/* 1=mm 2=inch 3=cm 4=m */
/* Pen number for thick lines */
/* Pen width for thick lines */
/* Pen speed */
/* Path for DXF-Files */
/* Installation drive */
/* Plotter number */
/* Printer number */
/* Printer Interface */
/* Plotter step size in mm */
/* Handshake 5= CTS oder 6= DSR(DEFAULT) 7 =

/* Plotter correction value */
/* Line thickness for POSTSCRIPT 1-8 */
/* Path for EDITOR-file */
/* DIGI-MOD 0=AUS 1=ON, COM No., Name */
/* Pfath for Infos-Macro */
/* Path for Outputfile Partlist*/
/* Path for Inputfile Partlist.* */
/* Digitizer Number */

```

# megacad.ini

```

FDI:C:\Megatech\MegaCAD 2014 (32) 3D\MCONFIG\*.DIG      /* Path for Digitiser assignment */
FDM:C:\Megatech\MegaCAD 2014 (32) 3D\MCONFIG           /* Path for Digitizer Menu tablet*/
KEY:C:\Megatech\MegaCAD 2014 (32) 3D\MCONFIG\*.KEU     /* Path for function key assignment files*/
DEF:1,2                                                 /* Key assignment for Digitiser - Mouse */
DL0:0.00,0.00                                           /* DINA4 Printer Resolution */
DL1:0.00,0.00                                           /* DINA3 Printer Resolution */
DL2:0.00,0.00                                           /* DINA2 Printer Resolution */
DL3:0.00,0.00                                           /* DINA3 132-Character Printer */
SCB:0                                                   /* Leave line empty on the botton*/
IGS:C:\Megatech\MegaCAD 2014 (32) 3D\igs\*.IGS         /* Path for IGS-Files */
CCP:                                                    /* Calcomp-Plotter */
PSF:                                                    /* ESC-Controll signs Postscrip */
WEX:" still activ!!"                                   /* windows-Escape message */
DWG:C:\Megatech\MegaCAD 2014 (32) 3D\dwg\*.DWG        /* Path for DWG-Files */
CIP:C:\Megatech\MegaCAD 2014 (32) 3D\CIP\*.CIP         /* Path for DWG-Files */
BMP:C:\Megatech\MegaCAD 2014 (32) 3D\IMAGES\*.BMP     /* Path for Bitmaps */
SAT:C:\Megatech\MegaCAD 2014 (32) 3D\SAT\*.SAT        /* Path for ACIS SAT files*/
STL:C:\Megatech\MegaCAD 2014 (32) 3D\STL\*.STL        /* Path for STL files */
WMF:C:\Megatech\MegaCAD 2014 (32) 3D\IMAGES\*.WMF     /* Path for WMF files */
DLL:C:\Programme\Megatech\MegaCAD 2014 (32) 3D\DLL\*.DLL /* Path for DLL files */
ATR:1                                                  /* Attributleiste on/off 0/1 */
BBC:RGB(255,0,0),2                                     /* Farbe der Feldumrandung im Bemassungs-Dialog */
BCC:RGB(255,192,0)                                     /* Hintergrundfarbe für Buttons im selektierten
Zustand */

```